


Repetition Module Assembly 70500-02000(s)



Parts List for Repetition Module Assembly 70500-02000(s)

70500-02000(s) PARTS LIST			
ITEM	PART N°	DESCRIPTION	QTY
1	07001-00114	10-24 UNC BUTTON HEAD SCREW	2
2	07001-00243	GRUB SCREW	1
3	07001-00250	M8 SOCKET HEAD CAP SCREW	1
4	07003-00248	'O' RING SEAL	1
5	07003-00028	'O' RING SEAL	1
6	07003-00033	BONDED SEAL	2
7	07003-00264	'O' RING SEAL	2
8	07003-00042	'O' RING SEAL	5
9	07003-00067	'O' RING SEAL	2
10	07003-00100	'O' RING SEAL	3
11	07003-00147	'O' RING SEAL	1
12	07003-00153	'O' RING SEAL	4
13	07003-00178	'O' RING SEAL	1
14	07003-00242	HYDRAULIC SEAL	1
15	07003-00243	HYDRAULIC SEAL	1
16	07004-00057	CIRCLIP	3
17	07007-00017	DUST CAP	1
18	07007-00353	PROTECTIVE PLUG	1
19	07151-00403	TURRET JAW	2
20	07271-01100	CURSOR ASSEMBLY	1
21	07650-00218	SPRING GUIDE	2
22	07650-00303	TURRET	1
23	07650-00501	BARREL LOCK NUT	2
24	07657-00302	ADAPTOR	1
25	07003-00036	'O' RING SEAL	1
26	07657-00305	PISTON	3
27	07657-00306	PISTON ROD	2
28	07657-00307	FRONT/REAR CYLINDER	2
29	07657-00308	REAR PLUG	1
30	07657-00309	SEAL RETAINER	3
31	07660-00202	BARREL WASHER	2
32	07667-00207	BARREL NUT	1
33	70500-02001	BARREL	1
34	70500-02002	SEAL SPRING GUIDE	1
35	70500-02003	BARREL SPRING RETAINER	1
36	70500-02004	BARREL SPRING	1
37	70500-02005	SPACER	1
38	70500-02006	BODY	1
39	70500-02007	PISTON GUIDANCE TAPE-LONG	1
40	70500-02008	PISTON GUIDANCE TAPE-SHORT	1
41	70500-02009	PISTON	1
42	70500-02010	TAIL JAW HOUSING	1
43	70500-02011	BANJO	1
44	70500-02012	FRONT CYLINDER	1
45	70500-02013	JAW HOUSING	1
46	70500-02014	LOCKNUT	1
47	70500-02015	PISTON NUT	1
48	70500-02016	BUFFER STOP	3
49	70500-02017	FRONT PISTON ROD	1
50	07273-00203	SAFETY LABEL	1*
51	07007-01503	'BOOK SYMBOL' LABEL	1*
52	07001-00481	GRUB SCREW M5 CUP	1

* Not shown